


T1V GETTING STARTED WITH T1V HUB



T1VHub™

Download the T1V app at t1v.com/app to join the Canvas remotely, share your screen, or control the Canvas from your personal device.



Connect using the 8-letter Room Code

If your Canvas is passcode protected, enter the 4 digit PIN when prompted



- 1 VIEW** the Hub board
- 2 CONTROL** the Hub board
- 3 VIRTUALLY POINT** on the Hub board
- 4 SHARE** your device screen or window to the Hub
- 5 SINGLE MODE** view a single device screen or window
- 6 QUAD MODE** view up to four device screens or windows when multiple devices are connected
- 7 SETTINGS**
- 8 LEAVE SESSION**

+1 704.594.1610 x56

T1V

customersuccess@t1v.com